



CPU Holder  
By MultiTable, LLC

2255 W Desert Cove Ave Suite E  
Phoenix, AZ 85029

602.773.6911  
customerservice@multitable.com

**www.MultiTable.com**




Swivel CPU Holder  
ASSEMBLY INSTRUCTIONS



Before assembly, please verify contents. Carefully remove contents from packaging. Check the contents for transit damage. Ensure all parts are in the box. In case of any damage or missing/incorrect parts, contact customer service at 602.773.6911 or [customerservice@multitable.com](mailto:customerservice@multitable.com).

Do not attempt to assemble the Swivel CPU Holder if there is any damage or are any missing/incorrect parts.



#### **PARTS CHECKLIST**

Part#	COMPONENT	QTY
A	Swivel Bracket	1
B	Bottom Bracket	1
C	CPU Clamp	1
D	Mounting Screws	4

#### **TOOLS CHECKLIST**

	Allen Wrench	1
--	--------------	---

#### **CAUTION:**

The CPU Holder and its components are low maintenance items, but still require regular maintenance. We recommend checking and tightening the screws every 6 months. Should your CPU Holder require repairs, please contact us. Any repairs or alterations should only be completed using approved replacement parts from MultiTable.

